



Revolution EXP hookup guide

Here's a quick look at how to use your Revolution EXP to add additional inputs to your audio interface via ADAT.

- Connect your preamp and line-level device outputs to the line inputs of the Revolution EXP using 1/4" balanced TRS cables.
- Connect the ADAT output of the Revolution EXP to the ADAT input of the interface.
- Connect the ADAT output of the interface to the ADAT input of the Revolution EXP.

- Finally, connect the Word Clock output of the Revolution EXP to the Word Clock input of your interface, if it has one.

For pro-level devices like those shown in this example, we recommend leaving the -10 dB switch off. If you're using a high-impedance instrument like a guitar or bass, be sure to connect that directly to your interface, using the hi-Z option, and not the Revolution EXP.

Preamp



Synth



Drum machine



Revolution EXP



Interface



Cables

1/4" TRS

ADAT

BNC

